

NOYES® One-Click Cleaner Series

Features

- Cleans connectors on jumpers and in adapters
- Low cost per clean
- Effective on a variety of contaminants including dust and oils
- Ergonomic, comfortable design with single action cleaning
- Automatic advance ensures each clean is performed with fresh cleaning tape
- Compliant with EU/95/2002/EC Directive (RoHS)
- Compact One-Click Cleaner Mini versions available
- Available with enlarged cleaning area up to 2 mm
- Duplex LC version available
- MPO/MTP version available



MU/LC

SC/ST/FC

ODC

The Original One-Click Cleaner

The One-Click Cleaner is an easy-to-use option for cleaning connectors on jumpers and in adapters. Simply insert the One-Click Cleaner into an adapter and push until an audible “click” is heard. The One-Click Cleaner uses the mechanical push action to advance an optical grade cleaning tape while the cleaning tip is rotated to ensure the fiber end-face is effectively, but gently cleaned. The One-Click Cleaner is a must-have for field technicians. Small enough to fit in a shirt pocket and a great addition to cleaning kits. Save your wrist – no more twist!



Mini-100 MU/LC

Mini-100 SC, ST, FC

Rugged ODC® Version

With the increasing demand of Outdoor Connector (ODC) plug and socket styles, the ODC One-Click Cleaner, which cleans the ferrules in ODC plug, socket and 1.25 mm ferrules, is an essential cleaning tool for WiMax Base Station, Fiber-to-the-Antenna, Broadcasting and Surveillance Video technicians.



Mini-500 MU/LC

Mini-500 SC, ST, FC

Compact One-Click Cleaner Mini

Offering the same technology and performance as the original, the One-Click Cleaner is now available in a smaller, more compact size, which allows for cleaning of connectors in tighter places. Its smaller size also makes it a great addition to test kits and cleaning kits. The One-Click Mini that is offered by AFL as a low cost solution with 100+ cleans per unit is now also available with same 500+ cleans per unit as the standard One-Click. The One-Click Mini is an effective, easy-to-use cleaning solution for SC, ST, FC, LC, MU and TFOCA connectors.



D-LC (Duplex LC)

2.5 Ultra

One-Click Cleaner MPO

NOYES® One-Click Cleaner Series

One-Click Cleaner Ultra 2.5

The One-Click Cleaner Ultra 2.5 has an enlarged cleaning area to clean more of the connector end-face. Cleaning up to a 2 mm diameter area of the connector end-face, the One-Click Cleaner Ultra 2.5 is a superior cleaner for SC, ST, and FC connectors.

One-Click Cleaner D-LC (Duplex LC)

Reduce cleaning time with the new One-Click Cleaner D-LC. Offering the same performance and easy-to-use one-click technology as the original, the One-Click Cleaner D-LC cuts cleaning time in half by effectively cleaning both LC connectors of a duplex LC at one time. 500+ duplex LC cleans per cleaner (1000+ LC connector cleans).

One-Click Cleaner MPO

Designed to clean MPO and MTP® multi-fiber connectors used in Data Centers and other high density optical networks, the new One-Click Cleaner MPO is a revolutionary push-type cleaner, which simplifies cleaning of the ferrule end-face of both MPO/ MTP exposed connectors and connectors in adapters. As with all One-Click Cleaners, the One-Click Cleaner MPO uses the innovative push-to-clean design. The mechanical push action advances the optical grade cleaning tape while effectively and gently cleaning the end-face of the connector.

Ordering Information

MODEL	DESCRIPTION	LENGTH	BASE	AFL NO.
One-Click SC, ST, FC	One-Click Cleaner SC, ST, FC (500 cleans)	172 mm (6.88 in)	17.5 x 17.5 mm (0.7 x 0.7 in)	8500-05-0001MZ
One-Click MU/LC	One-Click Cleaner MU/LC (500 cleans)	172 mm (6.88 in)	17.5 x 17.5 mm (0.7 x 0.7 in)	8500-05-0002MZ
One-Click ODC	One-Click Cleaner ODC (outdoor connector, 500 cleans)	172 mm (6.88 in)	17.5 x 17.5 mm (0.7 x 0.7 in)	8500-05-0004MZ
One-Click Mini-100 SC, ST, FC	One-Click Cleaner Mini-100 SC, ST, FC (100 cleans)	120.65 mm (4.75 in)	17.5 x 30.2 mm(0.7 x 1.2 in)	8500-05-0005MZ
One-Click Mini-100 MU/LC	One-Click Cleaner Mini-100 MU/LC (100 cleans)	120.65 mm (4.75 in)	17.5 x 30.2 mm(0.7 x 1.2 in)	8500-05-0006MZ
One-Click Mini-500 SC, ST, FC	One-Click Cleaner Mini-500 SC, ST, FC (500 cleans)	120.65 mm (4.75 in)	17.5 x 30.2 mm(0.7 x 1.2 in)	8500-05-0009MZ
One-Click Mini-500 MU/LC	One-Click Cleaner Mini-500 MU/LC (500 cleans)	120.65 mm (4.75 in)	17.5 x 30.2 mm(0.7 x 1.2 in)	8500-05-0010MZ
One-Click Ultra Cleaner 2.5	One-Click Ultra Cleaner 2.5 SC, ST, FC (enlarged cleaning area, 500 cleans)	203.2 mm (8 in)	22.2 x 33.3 mm (0.8 x 1.3 in)	8500-05-0007MZ
One-Click D-LC	One-Click Ultra Cleaner D-LC (Duplex LC, 500 cleans x 2)	195 mm (7.7 in)	18 x 30 mm (0.7 x 1.2 in)	8500-05-0008MZ
NEW One-Click MPO	One-Click Cleaner MPO (MPO/MTP®, 500 cleans)	203.2 mm (8 in)	19 x 44.5 mm (0.8 x 1.8 in)	8500-05-0030MZ



NOYES International Sales and Service Contact Information

Available at www.AFLglobal.com/NOYES/Contacts